

**INSTALLATION & OPERATION INSTRUCTION MANUAL**  
**FOR**  
**AIR-COOLED (HEAT PUMP) MODULAR UNIT**

**FISHER**  
**CAM-H300C-3F**  
**CAM-H650C-3F**  
**CAM-H1300C-3F**

Thank you for choosing our company products!

Air conditioning facilities are valuable products. In order to protect your legitimate rights and interests, please make sure that the installations are made by professional technicians. This manual is a general-purpose version for the conditioning systems manufactured by our CO., the one that you have chosen might be a little different in appearance from the ones described in the Manual. But these differences will not have any impacts upon your operation and use of the system.

Please read the manual carefully before you operate the system and check to see if the model is identical to the one you have purchased, keep the manual properly in case you might refer to it in the future.

This product you use is Central air-conditioning water system series and needs the regular cleaning and maintenance to reduce the faults and prolong the service life. Besides, a complete cleaning can clean up the dust inside the air conditioner and provide a good air and cut down the power consumption.

Keep the unit idle when the environment temperature is lower than 2°C and drain off the water in the water system before power failure. Please call the local central air-conditioning product service center for maintenance or troubleshooting before cooling operation in summer or the heating operation in winter.

## CONTENTS

## PAGE

|  |    |
|--|----|
| Part I PRECAUTION                        | 1  |
| Part II INTRODUCTION OF THE PRODUCT      | 4  |
| Part III INTRODUCTION OF WIRE CONTROLLER | 7  |
| Part IV TRANSPORTATION                   | 13 |
| Part V INSTALLATION OF THE UNIT          | 14 |
| Part VI WATER SYSTEM INSTALLATION        | 20 |
| Part VII ELECTRIC WIRING                 | 31 |
| Part VIII TRIAL RUN                      | 34 |
| Part IX MAINTENANCE AND UPKEEP           | 36 |
| Part X TECHNICAL PARAMETERS              | 44 |
| Part XI ATTACHMENTS                      | 45 |

# PRECAUTIONS

**To prevent injury to the user or other people and property damage, the following instructions must be followed. Incorrect operation due to ignoring of instructions may cause harm or damage.**

The safety precautions listed here are divided into two categories. In either case, important safety information is listed which must be read carefully.



## **WARNING**

Failure to observe a warning may result in death.



## **CAUTION**

Failure to observe a caution may result injury or damage to the equipment.



## **WARNING**

- Ask your dealer for installation of the air conditioner.  
Incomplete installation performed by yourself may result in a water leakage, electric shock, and fire.
- Ask your dealer for improvement, repair, and maintenance.  
Incomplete improvement, repair, and maintenance may result in a water leakage, electric shock, and fire.
- In order to avoid electric shock, fire or injury, or if you detect any abnormality such as smell of fire, turn off the power supply and call your dealer for instructions.
- Never replace a fuse with that of wrong rated current or other wires when a fuse blows out.  
Use of wire or copper wire may cause the unit to break down or cause a fire.
- Do not insert fingers, rods or other objects into the air inlet or outlet.  
When the fan is rotating at high speed, it will cause injury.
- Never use a flammable spray such as hair spray, alcohol or paint near the unit. It may cause a fire.
- Never inspect or service the unit by yourself.  
Ask a qualified service person to perform this work.
- Do not dispose this product as unsorted municipal waster. Collection of such waste separately for special treatment is necessary.
- Keep far away from high-frequency equipment.
- Keep away from the following places: a place where it is full of oil gas; places where salty air surrounding(near the coast); a place where is caustic gas(the sulfide in hot spring). Location in the folling places may cause malfunction or shorten the life span of the machine.
- In the case of extremely strong wind, please prevent the air from flowing backwards into the outdoor unit.
- Snow canopy is necessary in snowfall places on the outdoor unit. Please consult the local dealer for details.
- In the frequent thunder struck place, lightning proof actions should be taken.

- To prevent refrigerant leak, contact your dealer.

When the system is installed and runs in a small room, it is required to keep the concentration of the refrigerant, if by any chance coming out, below the limit. Otherwise, oxygen in the room may be affected, resulting in a serious accident.

- The refrigerant in the air conditioner is safe and normally does not leak.

If the refrigerant leaks in the room, contact with a fire of a burner, a heater or a cooker may result in a harmful gas.

- Turn off any combustible heating devices, ventilate the room, and contact the dealer where you purchased the unit.

Do not use the air conditioner until a service person confirms that the portion where the refrigerant leaks is repaired.



### **CAUTION**

---

- Do not use the air conditioner for other purposes.

In order to avoid any quality deterioration, do not use the unit for cooling precision instruments, food, plants, animals or works of art.

- Before cleaning, be sure to stop the operation, turn the breaker off or pull out the supply cord. Otherwise, an electric shock and injury may result.

- In order to avoid electric shock or fire, make sure that an earth leak detector is installed.

- Be sure the air conditioner is grounded.

In order to avoid electric shock, make sure that the unit is grounded and that the earth wire is not connected to gas or water pipe, lightning conductor or telephone earth wire.

- In order to avoid injury, do not remove the fan guard of the outdoor unit.

- Do not operate the air conditioner with a wet hand. An electric shock may happen.

- Do not touch the heat exchanger fins. These fins are sharp and could result in cutting injuries.

- After a long use, check the unit stand and fitting for damage. If damaged, the unit may fall and result in injury.

- To avoid oxygen deficiency, ventilate the room sufficiently if equipment with burner is used together with the air conditioner.

- Arrange the drain hose to ensure smooth drainage.

Incomplete drainage may cause wetting of the building, furniture etc.

- Never expose little children, plants or animals directly to the air flow.

Adverse influence to little children, animals and plants may result.

- Notice to avoid places where operation noise may easily be spread away or be enhanced.

- Noise can be amplified by anything blocking the air outlet of outdoor unit.

- Choose a proper place that the noise and hot or cold wind blown out of the outdoor unit will not bring inconvenience to your neighbors and not affect the growth of animal or plant.

- Recommending locate and operate the equipment at the altitude height not exceeded than 1000m.

- Endurable temperature during transportation is -25°C ~55°C . Such equipment could endure 70°C of the maximum temperature in 24hours.
- Do not allow a child to mount on the outdoor unit or avoid placing any object on it. Falling or tumbling may result in injury.
- Do not operate the air conditioner when using a room fumigation - type insecticide. Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.
- Do not place appliances which produce open fire in places exposed to the air flow from the unit or under the indoor unit. It may cause incomplete combustion or deformation of the unit due to the heat.
- Do not install the air conditioner at any place where flammable gas may leak out. If the gas leaks out and stays around the air conditioner, a fire may break out.
- The appliance is not intended for use by young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.

# INTRODUCTION OF THE PRODUCT

## Main parts of the unit




Fig 1 (a) Applicable for 30 kW units




Fig 1 (b) Applicable for 50kW, 60kW and 65kW units




Fig 1 (c) Applicable for 130kW units

#### Notes:

The sketch diagrams in this manual are just for references, the product you purchased may be different from these figures in shape or function, but it doesn't affect your use.

## Operation and performance

### ■ Performance characteristics of the unit

The air-cooled heat pump modular unit is composed of one or more modules. Each module has its own independent electric control unit, and the electric control units of modules conduct information exchange through communication network. The air-cooled heat pump modular unit is characteristics of compact structure and easy transportation and lifting, and in the meanwhile, it also saves facilities, including cooling tower, cooling pump, and so on, for the user, and reduces installation cost.

The units provide central air handling devices or terminal equipment with chilled water or hot water. The unit is a completely independent entirety type one, which is designed to be installed outdoors (on the ground or the roof). Each unit includes such main parts as high-efficient and low-noise scroll compressor, air-cooled condenser, shell and tube (or plate) evaporator, micro-computer control center, and so on. These parts are installed on steel structure base, so they are sound and durable.

The unit applies Chinese micro-computer control system, which can automatically conduct energy control according to the magnitude of load, to achieve optimal matching and thus actually realizing optimal energy-saving operation. The product is modularized unit, and parallel connection of 16 modules can be realized at most, so the user can adopt module combination according his own demands. The product can be widely applied in air-conditioning engineering of various newly-built and rebuilt industrial and civil buildings, such as restaurant, hotel, apartment, office building, hospital, industrial plant, and so on. The air-cooled heat pump modular unit is the best choice for the place which has high requirement in noise and ambient environment and which is short of water.

## ■ Use conditions of the unit

a. To maintain better performance, please operate the unit under the following outdoor temperature:

| Operating range under cooling mode | Operating range under heating mode |
|------------------------------------|------------------------------------|
| 21°C ~ 46°C                        | -10°C ~ 21°C                       |

b. The unit is of inlet water temperature control mode

Inlet water temperature control—cooling: minimum temperature 9°C , maximum temperature 22°C ;

heating: minimum temperature 35°C , maximum temperature 46°C .

If low-temperature water inlet unit is required, it should specially be customized.



**If the user requires the unit to operate under the outlet water temperature is lower than the minimum setting value mentioned above, be sure to make the requirement to the dealer or our maintenance center, and necessary protective measures should be taken before the unit is used.**



# INTRODUCTION OF WIRE CONTROLLER

## Constitution of Wire panel

### ■ Parts of the panel are as follow

- 1) One wire controller DM602A
- 2) One electric control panel: LY516A or LY517A
- 3) Temperature probes (The number is depended on the actual order)
- 4) Others (No)

### ■ Connection wires specification of Control panels:

- 1) HT381 Conector cable: Solid cable diameter ( $0.08-1.5\text{mm}^2$ ), specification (28-16AWG), Length of stripped wire (7mm), fixing screw (M2.0), screw torque (0.2-0.25NM)
- 2) HT508 Conector cable: Solid cable diameter ( $0.20-2.5\text{mm}^2$ ), specification (24-12AWG), Length of stripped wire (7mm), fixing screw (M2.5), screw torque (0.4-0.50NM)

## Product marking

Don't tear up the silver lable affixed to the front or back of the controller, for it will be helpful for check.

For example:

Product code: H. DM602A. 001


Product serial number: OW041622-090402-0251420

Function code of Delivery software: X1. DM602A. TY. F01C

Version number of Delivery software (Unit code): V200A0 (I. DM602A. 001)

## Monitor introduction

### ■ DM602A Monitor installation and its dimension: unit mm




- The number 0~7 can be used for password setting, while the number 8 and 9 will be replaced by 0 and 1 separately
- ON/OFF button, RESET button and SET buttons are not set with the corresponding number.



- ## 2. Display section:



3) Operating states of equipment:



When it turns on, it means defrosting function.

Number

When it turns on, it means that the corresponding compressor is defrosting;  
When it flashes, it means the forced-defrost order is received.



When it turns on, it means that the electric heating is operating;  
When it flashes, it means the unit is carrying on preheating operation

4) Buttons state:



Buttons locked



Invalid button


## Interface display and its operation instruction

### User operation instruction


Before boot-strap, please check whether all wire connections are OK.

1. Summary:

Electrifying→Boot-strap interface → Operation main interface




2. Boot-strap interface:



The boot screen displays the software function codes and vision No. of DM602A within the first five seconds.

F01: Function code(such as DM602A.TY.F01C)  
V200: Vision NO.(such as V200), displaying 3s and A0, displaying 2s;



The boot screen displays the software function codes and vision No. of DM602A within the latter five seconds.

B01: Function code(such as LY514A.TY.B01C)  
V200: Vision NO.(such as V200), displaying 3s and A0, displaying 2s;

Remarks: The function codes and vision No. Above are just fore reference.

### 3. Main operation interface

Press RESET key or countdown, the system will enter to the main operation interface:



The preheating operation will be started after electrifying as if the preheating time is not zero. During preheating operation, the unit can not be started until the operation is over.

If flashes, it means preheating operation and the operation can be cancelled by pressing down at the same time;

If turns on, it means that the auxiliary electric heating is effective and can be started.

means all buttons on the panel are locked;

means the button is invalid.


Press and simultaneously to switch LOCK/UNLOCK operation

Means defrost state of 1~4 modules

+ : The current module will carry on forced-defrost operation.

means timing operation and it will be started or shut down by pressing .

System module and status



means module code and 00 is the default value and the number will change by pressing .

Equipment states: No. 1 Compressor runs  
No. 1 Compressor is defrosting  
No. 1 Electric heater runs

Flashes for fault display and the system will enter to the fault check interface by pressing .

The heat recovery temperature is indicated only when the heat recovery function is started up

The system inlet water temperature or outlet water temperature is indicated for I. T setting or O. T setting.


If icon is indicated, it means sensor fault or the measuring value is out of the setting value.

### 4. State check




Module No. : 00~15  
SRI addresses: 0~F

Operation main interface



State of No. 00 module



State of No. 01 module



FF without any information


The switch of module No. is in the range of setting value

FF means system information


State check interface



xx% means the opening of electric expansion valve



XxA means the compressor current



State code:

T0xx: System state

Tnxx: No. n compressor state (n=1, 2, 3, 4)

T9xx: The current module state

Press or to switch the check of T0xx, Tnxx and T9xx

● Press to return to the main interface

● If no button is pressed within 180s, the system will return to the main interface automatically.

## 5. Fault check

Operation main interface




Module No. : 00~15

SRI addresses: 0~F

The interface displays the No. xx module fault

The switch of module No. is in the range of setting value

FF means system information




Press or to switch the check of T0xx, Tnxx and T9xx

- Press to return to the main interface
- If no button is pressed within 180s, the system will return to the main interface automatically.

## 6. TEMP. /MODE setting


Operation main interface



Setting 1 Setting 2


- If no button is pressed within 180s, the system will return to the main interface automatically.

T. SET. Means setting temperature and it means the current temperature when flashing.



It is effective only if the setting 0 is set.

Operation main interface




It means the current code when flashing



- If no button is pressed within 180s, the system will return to the main interface automatically.


## 7. Current time setting



- If no button is pressed within 180s, the system will return to the main interface automatically.

Press or to switch the check of T0xx, Tnxx and T9xx


## 8. Timing time setting



### Remarks:


There are 10 timing settings (00~10), each setting can be set separately at the any time and it is noneffective if the time is set for 00:00 or in the time from Saturday to Sunday.

The settings don't change for starting or shutting down timing operation.




## 9. Parameter setting

⚠ Please press to enter the parameter setting interface after inputting the password and keep the password right!



● Parameter initializing: Please follow the steps below to carry on parameter initializing operation



# TRANSPORTATION

## ■ Handling of the unit

The angle of inclination should not be more than  $15^\circ$  when carrying the unit, to avoid overturn of the unit.

- Rolling handling: several rolling rods of the same size are placed under the base of the unit, and the length of each rod must be more than the outer frame of the base and suitable for balancing of the unit.
- Lifting: the strength lifting rope (belt) can bear should be 3 times the weight of the unit. Check the lifting hook and ensure that it is firmly attached to the unit, and the lifting angle should be more than  $60^\circ$ . To avoid damages to the unit, the contact position of the unit and lifting rope should be provided with an at least 50mm thick wood block, cloth or hard paper. Any person is not allowed to stand below the unit when lifting it.




Fig 1




Fig 2

# INSTALLATION OF THE UNIT

## A. Selection of installation sites

- The unit can be installed on the ground or on the suitable roof, but enough ventilation volume should be ensured in both cases.
- The unit should not be installed where noise and vibration are required to a certain extent.
- The installed unit should be sheltered from direct sunlight as much as possible, and be far away from boiler flues and ambient air which may erode condenser coils and copper tube parts of the unit.
- If the installed unit can be approached by unauthorized persons, safety measures of isolation should be taken, such as rail guards. These measures will avoid artificial damages and accidental damages, and prevent the control boxes from being opened leading to exposure of electric components in operation.
- The height of the installation foundation for the unit should not be less than 300mm, and floor drains are required in installation sites, to ensure smooth drainage and remove any seepers.
- In case of installation on the ground, the steel base of the unit should be located on the concrete foundation, and the concrete plinth should extend below frozen soil layer. The foundation of the unit should not be connected to the foundation of the building, to avoid affecting the people due to transfer of noise and vibration. The base of the unit is provided with installation holes, which can be used to connect the unit and the foundation firmly.
- In case of installation on the roof, the roof must possess enough strength to sustain weight of the unit and maintenance personnel. The unit can be supported on concrete foundations or channel steel frames similar to those used in the unit installation on the ground. The load-bearing channel steel must be in alignment with the installation holes of the unit damper, and the channel steel should possess enough width for installing the damper.
- Consult the building contractor, the architectural designer or other specialists about the cases with special installation requirements.



## NOTE

The selected installation site of the unit should facilitate connection of water pipes and wires, and be free from water inlet of oil fume, steam or other heat sources. Besides, the noise of the unit and cold and hot air should not influence the surrounding environment.

## B. Outline dimensional drawing




Fig 1 Applicable for 30kW units






Fig 2 Applicable for 50kW, 60kW and 65kW units




Fig 3 Applicable for 130kW units

Table 1: unit (mm)

| Rated cooling capacity (kW) | A    | B    | C    | D   | E    | F   | G    | H    |
|-----------------------------|------|------|------|-----|------|-----|------|------|
| 30                          | 1160 | 900  | 2090 | --  | 150  | 460 | 840  | 850  |
| 65                          | 2000 | 900  | 2090 | 386 | 1420 | 522 | 1586 | 850  |
| 130                         | 2000 | 1700 | 2090 | 347 | 1420 | 510 | 1586 | 1640 |



### NOTE

- After installing the spring damper, the total height of the unit will increase by 135mm or so.
- The ports of inlet and outlet pipes should be flange ports, and flanges should be hubbed slip-on-welding steel pipe flanges.

## C. Requirements of arrangement space of the unit

### Requirements of arrangement space of the unit

- To ensure adequate airflow entering the condenser, the influence of descending airflow caused by the high-rise buildings around upon the unit should be taken into account when installing the unit.
- If the unit is installed where the flowing speed of air is high, such as on the exposed roof, the measures including sunk fence and Persian blinds can be taken, to prevent the turbulent flow from disturbing the air entering the unit. If the unit needs to be provided with sunk fence, the height of the latter should not be more than that of the former; if Persian blinds are required, the total loss of static pressure should be less than the static pressure outside the fan. The space between the unit and sunk fence or Persian blinds should also meet the requirement of the minimum installation space of the unit.
- If the unit needs to operate in winter, and the installation site may be covered by snow, the unit should be located higher than the snow surface, to ensure that air flows through the coils smoothly. The unit should not be installed where noise and vibration are required to a certain extent.

Arrangement space of the unit




Fig 4 Applicable for 30kW units




Fig 5 Applicable for 50kW, 60kW and 65kW units




Fig 6 Applicable for 130kW units

Table 2

| Installation space (mm) |       |       |       |       |
|-------------------------|-------|-------|-------|-------|
| A                       | B     | C     | D     | E     |
| >1500                   | >2000 | >2000 | >1500 | >8000 |

## Space requirements for parallel installation of multiple modular units

To avoid back flow of the air in the condenser and operational faults of the unit, the parallel installation of multiple modular units can follow the direction A and D as shown in the figure above, the spaces between the unit and the obstacle are given in the table above, and the space between adjacent modular units should not be less than 300mm; the installation can also follow the direction B and C as shown in the figure above, the spaces between the unit and the obstacle are given in Table 2, and the space between adjacent modular units should not be less than 600mm; the installation can also follow the direction combination of A and D, and B and C, the spaces between the unit and the obstacle are given in Table 2, the space between adjacent modular units in the direction A and D should not be less than 300mm, and the space between adjacent modular units in the direction B and C should not be less than 600mm. If the spaces mentioned above cannot be met, the air passing from the unit to the coils may be restricted, or back flow of air discharge may occur, and the performance of the unit may be affected, or the unit may fail to operate.

## C. Installation foundation

- The unit should be located on the horizontal foundation, the ground floor or the roof which can bear operating weight of the unit and the weight of maintenance personnel. Refer to Technical Parameters for operating weight.
- If the unit is located so high that it is inconvenient for maintenance personnel to conduct maintenance, the suitable scaffold can be provided around the unit.
- The scaffold must be able to bear the weight of maintenance personnel and maintenance facilities.
- The bottom frame of the unit is not allowed to be embedded into the concrete of installation foundation.

### ■ Location drawing of installation foundation of the unit: (unit: mm)





Fig 7 Applicable for 30kW units





Fig 8 Applicable for 50kW, 60kW and 65kW units





Fig 9 Applicable for 130kW units

## D. Installation of damping devices

### ■ Damping devices must be provided between the unit and its foundation.

By means of the  $\Phi 15\text{mm}$  diameter installation holes on the steel frame of the unit base, the unit can be fastened on the foundation through the spring damper. See Fig 7, Fig 8 and Fig 9 (Schematic diagram of installation dimension of the unit) for details about center distance of the installation holes. The damper does not go with the unit, and the user can select the damper according to the relevant requirements. When the unit is installed on the high roof or the area sensitive to vibration, please consult the relevant persons before selecting the damper.

### ■ Installation steps of the damper

Step 1. Make sure that the flatness of the concrete foundation is within  $\pm 3\text{mm}$ , and then place the unit on the cushion block.

Step 2. Raise the unit to the height suitable for installation of the damping device.

Step 3. Remove the clamp nuts of the damper.

Step 4. Place the unit on the damper, and align the fixing bolt holes of the damper with the fixing holes on the unit base.

Step 5. Return the clamp nuts of the damper to the fixing holes on the unit base, and tighten them into the damper.

Step 6. Adjust the operational height of the damper base, and screw down the leveling bolts. Tighten the bolts by one circle to ensure equal height adjustment variance of the damper.

Step 7. The lock bolts can be tightened after the correct operational height is reached.




Fig 10



## NOTE

It is recommended that the damper should be fastened on the foundation with the provided holes. After the unit is placed on the foundation, the damper connected with the unit should not be moved, and the central clamp nut is not allowed to be tightened before the damper sustains load.

# WATER SYSTEM INSTALLATION

## A. Basic requirements of connection of chilled water pipes



### CAUTION

- **After the unit is in place, chilled water pipes can be laid.**
- **The relevant installation regulations should be abided with when conducting connection of water pipes.**
- **The pipelines should be free of any impurity, and all chilled water pipes must conform to local rules and regulations of pipeline engineering.**

### ■ Connection requirements of chilled water pipes

- All chilled water pipelines should be thoroughly flushed, to be free of any impurity, before the unit is operated. Any impurity should not be flushed to or into the heat exchanger.
- Water must enter the heat exchanger through the inlet; otherwise the performance of the unit will decline.
- The inlet pipe of the evaporator must be provided with a target flow controller, to realize flow-break protection for the unit. Both ends of the target flow controller must be supplied with horizontal straight pipe sections whose diameter is 5 times that of the inlet pipe. The target flow controller must be installed in strict accordance with "Installation & Regulation Guide for Target Flow Controller" (Figure 4). The wires of the target flow controller should be led to the electric cabinet through shielded cable (see Electric Controlling Schematic Diagram for details). The working pressure of the target flow controller is 1.0MPa, and its interface is 1 inch in diameter. After the pipelines are installed, the target flow controller will be set properly according to the rated water flow of the unit.
- The pump installed in the water pipeline system should be equipped with starter. The pump will directly press water into the heat exchanger of the water system.
- The pipes and their ports must be independently supported but should not be supported on the unit.
- The pipes and their ports of the heat exchanger should be easy to disassemble for operation and cleaning, as well as inspection of port pipes of the evaporator.
- The evaporator should be provided with a filter with more than 40 meshes per inch at site. The filter should be installed near to the inlet port as much as possible, and be under heat preservation.
- The by-pass pipes and by-pass valves as shown in Fig. 1, Fig 2 and Fig 3 must be mounted for the heat exchanger, to facilitate cleaning of the outside system of water passage before the unit is adjusted. During maintenance, the water passage of the heat exchanger can be cut off without disturbing other heat exchangers.
- The flexible ports should be adopted between the interface of the heat exchanger and on-site pipeline, to reduce transfer of vibration to the building.
- To facilitate maintenance, the inlet and outlet pipes should be provided with thermometer or manometer. The unit is not equipped with pressure and temperature instruments, so they need to be purchased by the user.
- All low positions of the water system should be provided with drainage ports, to drain water in the evaporator and the system completely; and all high positions should be supplied with discharge valves, to facilitate expelling air from the pipeline. The discharge valves and drainage ports should not be under heat preservation, to facilitate maintenance.
- All possible water pipes in the system to be chilled should be under heat preservation, including inlet pipes and flanges of the heat exchanger.
- The outdoor chilled water pipelines should be wrapped with an auxiliary heating belt for heat preservation, and the material of the auxiliary heat belt should be PE, EDPM, etc., with thickness of 20mm, to prevent the pipelines from freezing and thus cracking under low temperature. The power supply of the heating belt should be equipped with an independent fuse.
- When the ambient temperature is lower than 2°C, and the unit will be not used for a long time, water inside the unit should be drained. If the unit is not drained in winter, its power supply should not be cut off, and the fan coils in the water system must be provided with three-way valves, to ensure smooth circulation of the water system when the anti-freezing pump is started up in winter.

o. The common outlet pipelines of combined units should be provided with mixing water temperature sensor.



## WARNING

- For the water pipeline network including filters and heat exchangers, dreg or dirt may seriously damages the heat exchangers and water pipes.
- The installation persons or the users must ensure the quality of chilled water, and de-icing salt mixtures and air should be excluded from the water system, since they may oxidize and corrode steel parts inside the heat exchanger.

### ■ Connection drawing of pipeline system




Fig 1




Fig 2




Fig 3

| Symbol explanation |                |                   |             |                           |
|--------------------|----------------|-------------------|-------------|---------------------------|
| Stop valve         | Pressure gauge | Water flow switch | Gate valve  | Flexible joint            |
| Y-shaped filter    | Thermometer    | Circulating pump  | Check valve | Automatic discharge valve |

## B. Water quality control

### ■ Water quality control

When industrial water is used as chilled water, little furring may occur; however, well water or river water, used as chilled water, may cause much sediment, such as furring, sand, and so on. Therefore, well water or river water must be filtered and softened in softening water equipment before flowing into chilled water system. If sand and clay settle in the evaporator, circulation of chilled water may be blocked, and thus leading to freezing accidents; if hardness of chilled water is too high, furring may occur easily, and the devices may be corroded. Therefore, the quality of chilled water should be analyzed before being used, such as PH value, conductivity, concentration of chloride ion, concentration of sulfide ion, and so on.



## ■ Applicable standard of water quality for the unit

Table 1

| PH value    | Total hardness | Conductivity           | Sulfide ion    | Chloride ion | Ammonia ion |
|-------------|----------------|------------------------|----------------|--------------|-------------|
| 7~8.5       | <50ppm         | <200 $\mu$ V/cm (25°C) | No             | <50ppm       | No          |
| Sulfate ion | Silicon        | Iron content           | Sodium ion     | Calcium ion  |             |
| <50ppm      | <30ppm         | <0.3ppm                | No requirement | <50ppm       |             |

## C. Installation & regulation guide for target flow controller

- Please carefully check flow switches before conducting installation of the target flow controller. Packing should be in good condition, and the appearance should be free of damage and deformation. If any problem, please contact the manufacturer.
- Flow switches can be installed in the horizontal pipeline or the vertical pipeline with upward flowing direction but cannot be mounted in the pipeline with downward flowing direction. The inlet water of gravity should be taken into account when flow switches are installed in the pipeline with upward flowing direction.
- Target flow controller must be installed on a section of straight-line pipeline, and its both ends must be supplied with straight-line pipes whose length is at least 5 times diameter of the pipe. In the meanwhile, the fluid flowing direction in the pipeline must be consistent with the direction of arrow on the controller. The connection terminal should be located where wiring connection can be easily done.
- Pay attention to the following items when conducting installation and wire connection:
  - a. Collision of the wrench with the soleplate of the flow switch is prohibited, since such collision may cause deformation and failure of the flow switch.
  - b. To avoid electric shock and damages to the devices, the power supply should be cut off, when wires are connected or adjustment is done.
  - c. When wiring connection is conducted, adjustment of other screws except connection terminals of micro switches and ground screws is prohibited. In the meanwhile, over great force should not be applied when wires of micro switches are connected, otherwise micro switches may suffer displacement, thus leading to failure of flow switches.
  - d. Special grounding screws should be used for earth connection. Bolts should not be installed or removed at will; otherwise flow switches may suffer deformation and failure.
  - e. Flow switches have been set at minimal flow value prior to ex-factory. They should not be adjusted below the ex-factory setting value, or they may suffer failure. After installing flow switches, please press the flow switch lever several times to check them. When the lever is found not to respond with "clatter", rotate the screw in a clockwise direction, until "clatter" occurs.
  - f. Be sure to determine the model of target slice according to the rated flow of the unit, the diameter of the outlet pipe and the adjustment range of the target slice of the flow switch. Besides, the target slice should not contact with other restrictors in the pipeline or on the inner wall of the pipeline, or the flow switch cannot be reset normally.

■ Determine whether the flow switch and the system connected with it are in good operation according to the measured value by flow meter, namely, when the measured value on flow meter is less than 60% of rated water flow of the unit, the target flow controller should be cut off and observed for 3 working periods, and it should be covered with flow switch shell timely.




Fig 4 Schematic diagram of target flow controller

#### D. Installation of single-module water system pipeline




Fig 5 Applicable for 30kW units




Fig 6 Applicable for 50kW, 60kW and 65kW units




Fig 7 Applicable for 130kW units

## E. Installation of multi-module water system pipeline

Multi-module combination installation involves special design of the unit, so relevant explanation is given as follows.

### ■ Installation mode of multi-module combination water system pipeline

1) The installation modes below are applicable for 30 kW units

a. Installation mode I (recommended installation mode)




Fig 8 (less than 16 modules)

b. Installation mode II




Fig 9 (less than 16 modules)

2) The installation modes below are applicable for 50kW, 60kW and 65kW units

a. Installation mode I (recommended installation mode)




Fig 10 (less than 6 modules)

b. Installation mode II




Fig 11 (less than 6 modules)

c. Installation mode III (recommended installation mode)




Fig12 (installation mode A: less than 16 modules)




Fig 13 (installation mode B: less than 16 modules)

d. Installation mode IV




Fig 14 (installation mode A: less than 12 modules)

Fig 15 (installation mode B: less than 12 modules)

e. Installation mode V




Fig 16 (installation mode A: less than 12 modules)

Fig 17 (installation mode B: less than 12 modules)

3) The installation modes below are applicable for 130kW units

a. Installation mode I (recommended installation mode)




Fig 18 (less than 16 modules)

b. Installation mode II




Fig 19 (less than 16 modules)

■ **Table of diameter parameters of main inlet and outlet pipes**

| Total cooling capacity<br>(Unit model x quantity) kW | Total inlet and outlet water<br>pipe diameters<br>(nominal diameter) | Total cooling capacity<br>(Unit model x quantity) kW | Total inlet and outlet water<br>pipe diameters<br>(nominal diameter) |
|--|--|--|--|
| (30 × 1=) 30   | <b>DN 40</b>   | (60 × 8=) 480  | <b>DN125</b>   |
| (60 × 1=) 60   | <b>DN 65</b>   | (65 × 8=) 520  |  |
| (65 × 1=) 65   |  | (60 × 9=) 540  |  |
| (130 × 1=) 130                                       |  | (65 × 9=) 585  |  |
| (30 × 2=) 60   |  | (60 × 10=) 600                                       |  |
| (60 × 2=) 120  |  | (65 × 10=) 650                                       |  |
| (65 × 2=) 130  |  | (30 × 14=) 420                                       |  |
| (30 × 3=) 90   |  | (30 × 15=) 450                                       |  |
| (30 × 4=) 120  |  | (30 × 16=) 480                                       |  |
| (30 × 5=) 150  |  | (130 × 6=) 780                                       |  |
| (60 × 3=) 180  | <b>DN 80</b>   | (130 × 7=) 910                                       | <b>DN150</b>   |
| (65 × 3=) 195  |  | (60 × 11=) 660                                       |  |
| (30 × 6=) 180  |  | (65 × 11=) 715                                       |  |
| (30 × 7=) 210  |  | (60 × 12=) 720                                       |  |
| (130 × 2=) 260                                       | <b>DN100</b>   | (65 × 12=) 780                                       |  |
| (130 × 3=) 390                                       |  | (60 × 13=) 780                                       |  |
| (60 × 4=) 240  |  | (65 × 13=) 845                                       |  |
| (65 × 4=) 260  |  | (60 × 14=) 840                                       |  |
| (60 × 5=) 300  |  | (65 × 14=) 910                                       |  |
| (65 × 5=) 325  |  | (130 × 8=) 1040                                      | <b>DN200</b>   |
| (60 × 6=) 360  |  | (60 × 15=) 900                                       |  |
| (65 × 6=) 390  |  | (65 × 15=) 975                                       |  |
| (30 × 8=) 240  |  | (60 × 16=) 960                                       |  |
| (30 × 9=) 270  |  | (65 × 16=) 1040                                      |  |
| (30 × 10=) 300                                       |  | (130 × 9=) 1170                                      |  |
| (30 × 11=) 330                                       |  | (130 × 10=) 1300                                     |  |
| (30 × 12=) 360                                       |  | (130 × 11=) 1430                                     |  |
| (30 × 13=) 390                                       |  | (130 × 12=) 1560                                     |  |
| (130 × 4=) 520                                       | <b>DN125</b>   | (130 × 13=) 1690                                     | <b>DN250</b>   |
| (130 × 5=) 650                                       |  | (130 × 14=) 1820                                     |  |
| (60 × 7=) 420  |  | (130 × 15=) 1950                                     |  |
| (65 × 7=) 455  |  | (130 × 16=) 2080                                     |  |



### CAUTION

**Please pay attention to the following items when installing multiple modules:**

- **Each module corresponds to an address code which cannot be repeated.**
- **Main water outlet temperature sensing bulb, target flow controller and auxiliary electric heater are under control of the main module.**
- **One wired controller and one target flow controller are required and connected on the main module.**
- **The unit can be started up through the wired controller only after all addresses are set and the aforementioned items are determined. The wired controller is ≤500m away from the outdoor unit.**



# ELECTRIC WIRING

## A. Electric wiring



### CAUTION

1. The air-conditioner should apply special power supply, whose voltage should conform to rated voltage.
2. Wiring construction must be conducted by the professional technicians according to the labeling on the circuit diagram.
3. Only use the electric components specified by our company, and require installation and technical services from the manufacturer or authorized dealer. If wiring connection fails to conform to electric installation norm, failure of the controller, electronic shock, and so on may be caused.
4. The connected fixed wires must be equipped with full switching-off devices with at least 3mm contact separation.
5. Set leakage protective devices according to the requirements of national technical standard about electric equipment.
6. After completing all wiring construction, conduct careful check before connecting the power supply.
7. Please carefully read the labels on the electric cabinet.
8. The user's attempt to repair the controller is prohibited, since improper repair may cause electric shock, damages to the controller, and so on. If the user has any requirement of repair, please contact the maintenance center.

## B. Power supply specification

Table 1


| Model       |   |                        | 30kW | 50 kW, 60kW<br>and 65kW | 130kW |
|-------------|---|------------------------|------|-------------------------|-------|
| Power lines | L | CSA (mm <sup>2</sup> ) | 10   | 16                      | 25    |
|             |   | number                 | 3    | 3                       | 3     |
|             | N | CSA (mm <sup>2</sup> ) | 6    | 10                      | 10    |
|             |   | number                 | 1    | 1                       | 1     |
|             | E | CSA (mm <sup>2</sup> ) | 6    | 10                      | 10    |
|             |   | number                 | 1    | 1                       | 1     |

Note: Above data for reference only and the models are shown by rated cooling capacity!

## C. Requirements of wiring connection

- No additional control components are required in the electric cabinet (such as relay, and so on), and the power supply and control wires not connected with the electric cabinet are not allowed to go through the electric box. Otherwise, electromagnetic interference may cause failure of the unit and control components and even damages to them, which thus lead to protective failure.

- All cables led to the electric box should be supported independently but by the electric box.
- The strong current wires generally pass the electric box, and 220-240V alternating current may also pass the control board, so wiring connection should conform to the principle of separation of strong current and weak current, and the wires of power supply should be kept more than 100 mm away from the control wires.
- All electric wires must conform to local wiring connection norm. The suitable cables should be connected to power supply terminal through wiring connection holes at the bottom of the electric cabinet. According to Chinese standard, the user is responsible for providing voltage and current protection for the input power supply of the unit.
- All power supplies connected to the unit must pass one manual switch, to ensure that the voltages on all nodes of electric circuit of the unit are released when the switch is cut off.
- The cables of correct specification must be used to supply power for the unit. The unit should use independent power supply, and the unit is not allowed to use the same power supply together with other electric devices, to avoid over-load danger. The fuse or manual switch of the power supply should be compatible with working voltage and current of the unit. In case of parallel connection of multiple modules, the requirements of wiring connection mode and configuration parameters for the unit are shown in the following figure.
- Some connection ports in the electric box are switch signals, for which the user needs to provide power, and the rated voltage of the power should be 220-240VAC. The user must be aware that all power supplies they provided should be obtained through power circuit breakers (provided by the user), to ensure that all voltages on the nodes of the provided power supply circuit are released when the circuit breakers are cut off.
- All inductive components provided by the user (such as coils of contactor, relay, and so on) must be suppressed with standard resistance-capacitance suppressors, to avoid electromagnetic interference, thus leading to failure of the unit and its controller and even damages to them.
- All weak current wires led to the electric box must apply shielded wires, which must be provided with grounding wires. The shield wires and power supply wires should be laid separately, to avoid electromagnetic interference.
- The unit must be provided with grounding wires, which are not allowed to be connected with the grounding wires of gas fuel pipelines, water pipelines, lightning conductors or telephones. Improper earth connection may cause electric shock, so please check whether earth connection of the unit is firm or not frequently.



## NOTE

**Only 16 modular units can be combined at most.**

## C. Wiring steps

- Step 1. Check the unit and ensure that it is connected with grounding wires correctly, to avoid leakage, and the grounding devices should be mounted in strict accordance with the requirements of electrical engineering rules. The grounding wires can prevent electric shock.
- Step 2. The control box of the main power switch must be mounted in a proper position.
- Step 3. Wiring connection holes of the main power should be provided with glue cushion.
- Step 4. The main power and neutral wires and grounding wires of power supply are led into the electric box of the unit.
- Step 5. The wires of the main power must pass the bonding clamp.
- Step 6. Wires should be connected firmly to the connection terminals L1, L2, L3 and N.
- Step 7. Phase sequences must be consistent when the wires of the main power.
- Step 8. The main power should be located out of easy reach of non-professional maintenance personnel, to avoid mal-operation and improve safety.
- Step 9. Connection of control wires of water flow switches: the wire leads (prepared by the user) of water flow switches are connected to the corresponding connection terminals of the main unit.
- Step 10. Connection of control wires of pump: the control wires of AC contactor of pump must pass the corresponding connection terminals of the main unit.

## D. Electric control schematic diagram of the unit

- Electric wiring diagrams of 30 kW unit (see Attached Drawing (I) and Attached Drawing (VI) )
- Electric wiring diagram of 50 kW unit (see Attached Drawing (II) )
- Electric wiring diagrams of 60 kW unit (see Attached Drawing (III) and Attached Drawing (VII))
- Electric wiring diagrams of 65 kW unit (see Attached Drawing (IV) and Attached Drawing (VIII))
- Electric wiring diagrams of 130 kW unit (see Attached Drawing (V) and Attached Drawing (IX))
- Schematic diagram of connection and communication of the main unit and subordinate units (see Attached Drawing (X))



### CAUTION

---

#### 1. Faults

**When the main unit suffers faults, the main unit stops operating, and all other units also stop running;**

**When the subordinate unit suffers faults, only the unit stops operating, and other units are not affected.**

#### 2. Protection

**When the main unit is under protection, only the unit stops operating, and other units keep running;**

**When the subordinate unit is under protection, only the unit stops operating, and other units are not affected.**

---

# TRIAL RUN

## A. Points for attention prior to trial run

- After the water system pipeline is flushed several times, please make sure that the purity of water meets the requirements; the system is re-filled with water and drained, and the pump is started up, then make sure that water flow and the pressure at the outlet meet the requirements.
- The unit is connected to the main power 12 hours before being started up, to supply power to the heating belt and pre-heat the compressor. Inadequate pre-heating may cause damages to the compressor.
- Setting of the wired controller. See details of the manual concerning setting contents of the controller, including such basic settings as refrigerating and heating mode, manual adjustment and automatic adjustment mode and pump mode. Under normal circumstances, the parameters are set around standard operating conditions for trial run, and extreme working conditions should be prevented as much as possible.
- Carefully adjust the target flow controller on the water system or the inlet stop valve of the unit, to make the water flow of the system be 90% of the water flow specified in Technical Parameters.

## B. Check item table after installation

| Check items  | Descriptions  | Yes | No |
|--|---|-----|----|
| Whether installing site is meet for requirements           | Units are fixed mounting on level base.   |     |    |
|  | Ventilating space for heat exchanger at the air side is meeting for requirement |     |    |
|  | Maintenance space is meeting for requirement.                                   |     |    |
|  | Noise and vibration is meeting for requirement.                                 |     |    |
|  | Sun radiation and rain or snow proof measures are meeting for requirements.     |     |    |
|  | External physical is meeting for requirement.                                   |     |    |
| Whether water system is meeting for requirements           | Pipe diameter is meeting for requirement  |     |    |
|  | The length of system is meeting for requirement.                                |     |    |
|  | Water discharge is meeting for requirement                                      |     |    |
|  | Water quality control is meeting for requirement                                |     |    |
|  | Flexible tube's interface is meeting for requirement                            |     |    |
|  | Pressure control is meeting for requirement                                     |     |    |
|  | Thermal insulation is meeting for requirement                                   |     |    |
| Whether electric wiring system is meeting for requirements | Wire capacity is meeting for requirement  |     |    |
|  | Switch capacity is meeting for requirement                                      |     |    |
|  | Fuse capacity is meeting for requirement  |     |    |
|  | Voltage and frequency are meeting for requirement                               |     |    |
|  | Connecting tightly between wires  |     |    |
|  | Operation control device is meeting for requirement                             |     |    |
|  | Safety device is meeting for requirement  |     |    |
|  | Chained control is meeting for requirement                                      |     |    |
|  | Phase sequence of power supply is meeting for requirement                       |     |    |

## C. Trial run

- Start up the controller and check whether the unit displays a fault code. If a fault occurs, remove the fault first, and start the unit according to the operating method in the “Introduction of Wire Controller”, after determining that there is no fault existing in the unit.
- Conduct trial run for 30 min. When the influent and effluent temperature becomes stabilized, adjust the water flow to nominal value, to ensure normal operation of the unit.
- After the unit is shut down, it should be put into operation 10 min later, to avoid frequent start-up of the unit. In the end, check whether the unit meets the requirements according to the contents in Technical Parameters.



### CAUTION

- **The unit can control start-up and shut-down of the unit, so when the water system is flushed, the operation of the pump should not be controlled by the unit.**
  - **Do not start up the unit before draining the water system completely.**
  - **The target flow controller must be installed correctly. The wires of the target flow controller must be connected according to electric control schematic diagram, or the faults caused by water breaking while the unit is in operation should be the user's responsibility.**
  - **Do not re-start the unit within 10 min after the unit is shut down during trial run.**
  - **When the unit is used frequently, do not cut off the power supply after the unit is shut down; otherwise the compressor cannot be heated, thus leading to its damages.**
  - **If the unit is not in service for a long time, and the power supply needs to be cut off, the unit should be connected to the power supply 12 hours prior to re-starting of the unit, to pre-heat the compressor.**
-

# MAINTENANCE AND UPKEEP

## A. Control and protection function of unit

### ■ The unit has the following protection functions

- 1) Current cut-off protection
- 2) Power supply phase sequence protection
- 3) Protection for over-low suction pressure
- 4) Protection for compressor over-current
- 5) Protection for compressor overload
- 6) Anti-freezing protection
- 7) Protection for over-high discharge pressure
- 8) Protection for outlet and inlet water temperature difference

### ■ The unit also has other control functions:

- 1) Manual test function
- 2) Plug and play system
- 3) RS-485/TS232 Standard serial communication port.

## B. Failure of wired controller and its reason

In case the unit runs under abnormal condition, failure protection code will display on both control panel and wired controller, and the indicator on the wired controller will flash with 5Hz. The display codes are shown in the following table:

FF System faults:

| Codes | Fault contents                        | Remarks                              |  | Codes | Fault contents                                 | Remarks |
|-------|---------------------------------------|--------------------------------------|--|-------|--|---------|
| 0     | Communication fault                   | Power fault of Main module           |  | 33    | Environment temperature sensor fault           |         |
| 1     | Power fault                           |                                      |  | 34    | System outlet water temperature sensor fault   |         |
| 2     | EEPROM data fault                     |                                      |  | 35    | System inlet water temperature sensor fault    |         |
| 3     | External chain alarm                  |                                      |  | 36    | Heat recovery temperature sensor fault         |         |
| 8     | Air conditioner pump overloading      |                                      |  | 40    | System outlet water temperature being too high |         |
| 9     | Air conditioner water in short supply | Water of Main module in short supply |  | 41    | System outlet water temperature being too low  |         |
| 10    | Heat recovery pump overloading        |                                      |  |       |  |         |
| 11    | Heat water in short supply            |                                      |  |       |  |         |

00-15# Module faults:

| Codes | Fault contents                                 | Remarks              |
|-------|--|----------------------|
| 48    | Pressure of 1# Compressor being too low        | 1# Compressor faults |
| 49    | Pressure of 1# Compressor being too high       |                      |
| 50    | 1# Compressor overheating                      |                      |
| 52    | 1# Suction temperature sensor fault            |                      |
| 53    | 1# Inlet temperature sensor of evaporate fault |                      |
| 55    | 1# Fin temperature sensor fault                |                      |
| 57    | Current of 1# Compressor being too low         |                      |
| 58    | 1# Fin temperature being too high              |                      |
| 60    | Current of 1# Compressor being too high        |                      |
| 80    | Pressure of 2# Compressor being too low        | 2# Compressor faults |
| 81    | Pressure of 2# Compressor being too high       |                      |
| 82    | 2# Compressor overheating                      |                      |
| 84    | 2# Suction temperature sensor fault            |                      |
| 85    | 2# Inlet temperature sensor of evaporate fault |                      |
| 87    | 2# Fin temperature sensor fault                |                      |
| 89    | Current of 2# Compressor being too low         |                      |
| 90    | 2# Fin temperature being too high              |                      |
| 92    | Current of 2# Compressor being too high        |                      |
| 177   | Power fault                                    | Module faults        |
| 178   | Module EEPROM data fault                       |                      |
| 182   | Module air conditioner water in short supply   |                      |
| 185   | 1# Fan overloading                             |                      |
| 186   | 2# Fan overloading                             |                      |
| 189   | Module air supply pressure difference          |                      |
| 192   | 1# Outlet water temperature sensor fault       |                      |
| 193   | 2# Outlet water temperature sensor fault       |                      |
| 196   | 1# Outlet water temperature overheating        |                      |
| 197   | 2# Outlet water temperature overheating        |                      |
| 200   | 1# Outlet water temperature overcooling        |                      |
| 201   | 2# Outlet water temperature overcooling        |                      |

## C. Troubleshooting

| Error   | Possible reason   | Detect and settle measure   |
|---|---|---|
| Over high air discharge pressure<br>(Cooling operation)                 | Air or other non-condensing gas still in the system                 | Discharge gas from fluorin charging inlet. Re-vacuum the system if necessary.                   |
|   | Fins in the condenser are dirty or foreign substance blocking fins. | Clean condenser fins.   |
|   | Insufficient chilling air volume or condenser fan error             | Check and repair the condenser fan, recover the normal operation                                |
|   | Excessive high air suction pressure                                 | See "Excessive high air suction pressure"   |
|   | Excessive refrigerant charging volume                               | Discharge the excessive refrigerant   |
|   | Over high ambient temperature                                       | Check ambient temperature   |
| Over low air discharge pressure<br>(Cooling operation)                  | Over cool air in the side of air heat exchanger                     | Check ambient temperature   |
|   | Refrigerant leakage or insufficient refrigerant volume              | Test leakage or charge sufficient refrigerant to the system                                     |
|   | Excessive low air suction pressure                                  | See "Excessive low air suction pressure"  |
| Over high air suction pressure<br>(Cooling operation)                   | Excessive refrigerant charging volume                               | Discharge the excessive refrigerant   |
|   | Over high temperature in chilling water inlet                       | Check thermal insulation layer of water pipe and the specification of this layer                |
| Over low air suction pressure<br>(Cooling operation)                    | Insufficient water flow volume                                      | Check temperature difference at water inlet and outlet, and adjust the water flow volume        |
|   | Over low temperature in chilling water inlet and outlet             | Check and installation state  |
|   | Refrigerant leakage or insufficient refrigerant volume              | Test leakage or charge sufficient refrigerant to the system                                     |
|   | Incrustant in evaporator  | Eliminate incrustant  |
| Over high air discharge pressure<br>(Heating operation)                 | Insufficient water flow   | Check temperature difference at water inlet and outlet, and adjust the water flow volume        |
|   | Air or other non-condensing gas still in the system                 | Discharge gas from fluorin charging inlet. Re-vacuum the system if necessary.                   |
|   | Incrustant in water side of heat exchanger                          | Eliminate incrustant  |
|   | Over high temperature in chilling water inlet                       | Check water temperature   |
|   | Excessive high air suction pressure                                 | See "Excessive high air suction pressure"   |
| Over low air discharge pressure<br>(Heating operation)                  | Over low temperature of chilling water                              | Check chilling water temperature  |
|   | Refrigerant leakage or insufficient refrigerant volume              | Test leakage or charge sufficient refrigerant to the system                                     |
|   | Excessive low air suction pressure                                  | See "Excessive low air suction pressure"  |
| Over high air suction pressure<br>(Heating operation)                   | Over heat air in the side of air heat exchanger                     | Check ambient temperature around it   |
|   | Excessive refrigerant charging volume                               | Discharge the excessive refrigerant   |
| Over low air suction pressure<br>(Heating operation)                    | Insufficient refrigerant charging volume                            | Charge sufficient refrigerant to the system   |
|   | Insufficient air flow volume  | Check fan rotating direction  |
|   | Air loop short-circuit  | Reason about remove air short-circuit   |
|   | Insufficient frost-removal operation                                | Error comes out from 4-way valve or thermal resistor. Replace a new one if necessary.           |
| Compressor stops because of freeze-proof protection (Cooling operation) | Insufficient chilling water flow volume                             | Error comes from pump or flow-type water volume control. Check and repair or replace a new one. |
|   | Gas still in water loop   | Discharge air   |
|   | Thermal resistor error  | Upon error have been confirmed, please replace a new one.                                       |
| Compressor stops because of Hi-pressure protection                      | Over high air expelling pressure                                    | See "Over high air expelling pressure"  |
|   | Hi-pressure switch error  | Upon error have been confirmed, please replace a new one.                                       |



| Error   | Possible reason   | Detect and settle measure   |
|---|---|---|
| Compressor stops because of motor Overcurrent.  | Over high air expelling pressure and air suction pressure                           | See "Over high air expelling pressure" and "Over high air suction pressure"         |
|   | Hi-voltage or Lo-voltage, signal phase or phase unbalance                           | Confirm voltage not higher or lower than the rated voltage 20V                      |
|   | Short circuit comes out from motor or connecting interface                          | Confirm resistors at motor are connected corresponding to terminals                 |
|   | Overcurrent assembly error  | Replace a new one   |
| Compressor stops because of integrate temperature sensor or air discharge temperature protection. | Over high or over low voltage   | Confirm voltage not higher or lower than the rated voltage 20V                      |
|   | Over high air expelling pressure or excessive low air suction pressure              | See "Over high air expelling pressure" and "excessive low air suction pressure "    |
|   | Component error   | Check the integrated temperature sensor after motor is cool down.                   |
| Compressor stops because of Lo.-pressure protection   | Filter in front (or rear) of expanding valve is blocked                             | Replace a new filter  |
|   | Lo-voltage switch error   | If the switch is defective, please replace a new one.                               |
|   | Excessive low air suction pressure  | See "Excessive low air suction pressure"  |
| Abnormal noise gives out from compressor  | Liquid refrigerant flows into compressor from evaporator result in liquid slugging. | Adjust refrigerant charge volume  |
|   | Aging of compressor   | Replace a new compressor  |
| Compressor is unable to drive   | Overcurrent relay trip up, fuse burnt out   | Replace damaged assembly  |
|   | Control circuit without power though  | Check the wiring of control system  |
|   | Hi-voltage or lo-voltage protection   | Reference to mention in above the parts of air suction and discharge pressure error |
|   | Coils in contactor are burnt out  | Replace damaged assembly  |
|   | Wrong connection of phase sequence  | Re-connect and adjust the any 2 wires among 3 phases                                |
|   | Water system error and flow type volume controller short connection                 | Check water system  |
|   | Error signal delivered from wire controller   | Find out the error type and carry out the corresponding measure to settle           |
| Air side heat exchanger excessive frost   | 4-way valve or thermal resistor error   | Check the running state. Replace a new one if necessary.                            |
|   | Air loop short-circuit  | Settle the short-circuit of air discharge   |
| With noise  | Fixing screws at panel are loosen   | Fix up all assemblies   |

## D. Care and maintenance

### ■ Maintenance of main parts

- Close attention should be paid to the discharge and suction pressure during the running process. Find out reasons and eliminate the failure if abnormality is found.
- Control and protect the equipment. See to it that no random adjustment be made on the set points on site.
- Regularly check whether the electric connection is loose, and whether there is bad contact at the contact point caused by oxidation and debris etc., and take timely measures if necessary. Frequently check the work voltage, current and phase balance.
- Check the reliability of the electric elements in time. Ineffective and unreliable elements should be replaced in time.

## ■ Removing scale

After long-time operation, calcium oxide or other minerals will be settled in the heat transfer surface of the water-side heat exchanger. These substances will affect the heat transfer performance when there is too much scale in the heat transfer surface and sequentially cause that electricity consumption increases and the discharge pressure is too high (or suction pressure too low). Organic acids such as formic acid, citric acid and acetic acid may be used to clean the scale. But in no way should cleaning agent containing fluoroacetic acid or fluoride should be used as the water-side heat exchange is made from stainless steel and is easy to be eroded to cause refrigerant leakage. Pay attention to the following aspects during the cleaning and scale-removing process:

- Water-side heat exchanger should be done by professionals. Please contact the local air-conditioner customer service center.
- Clean the pipe and heat exchanger with clean water after cleaning agent is used. Conduct water treatment to prevent water system from being eroded or re-absorption of scale.
- In case of using cleaning agent, adjust the density of the agent, cleaning time and temperature according to the scale settlement condition.
- After pickling is completed, neutralization treatment needs to be done on the waste liquid. Contact relevant company for treating the treated waste liquid.
- Protection equipments (such as goggles, gloves, mask and shoes) must be used during the cleaning process to avoid breathing in or contacting the agent as the cleaning agent and neutralization agent is corrosive to eyes, skins and nasal mucosa.

## ■ Winter shutdown

For shutdown in winter, the surface of the unit outside and inside should be cleaned and dried. Cover the unit to prevent dust. Open discharge water valve to discharge the stored water in the clean water system to prevent freezing accident (it is preferable to inject antifreezer in the pipe).

## ■ Replacing parts

Parts to be replaced should be the ones provided by our company. Never replace any part with different part.

## ■ First startup after shutdown

The following preparations should be made for re-startup of unit after long-time shutdown:

- 1) Thoroughly check and clean the unit.
- 2) Clean water pipe system.
- 3) Check pump, control valve and other equipments of water pipe system.
- 4) Fix connections of all wires.
- 5) It is a must to electrify the machine before startup.

## ■ Refrigeration system

Determine whether refrigerant is needed by checking the value of suction and discharge pressure and check whether there is a leakage. Air tight test must be made if there is a leakage or parts of refrigerating system is to be replaced. Take different measures in the following two different conditions from refrigerant injection.

1) Total leakage of refrigerant. In case of such situation, leakage detection must be made on the pressurized nitrogen used for the system. If repair welding is needed, welding cannot be made until all the gas in the system is discharged. Before injecting refrigerant, the whole refrigeration system must be completely dry and of vacuum pumping.

- Connect vacuum pumping pipe at the fluoride nozzle at low-pressure side.
- Remove air from the system pipe with vacuum pump. The vacuum pumping lasts for above 3 hours.

Confirm that the indication pressure in dial gauge is within the specified scope.

- When the degree of vacuum is reached, inject refrigerant into the refrigeration system with refrigerant bottle. Appropriate amount of refrigerant for injection has been indicated on the nameplate and the table of main technical parameters. Refrigerant must be injected from the low pressure side of system.
- The injection amount of refrigerant will be affected by the ambient temperature. If the required amount has not been reached but no more injection can be done, make the chilled water circulate and start up the unit for injection. Make the low pressure switch temporarily short circuit if necessary.

2) Refrigerant supplement. Connect refrigerant injection bottle on the fluoride nozzle at low-pressure side and connect pressure gauge at low pressure side.

- Make chilled water circulate and start up unit, and make the low pressure control switch short circuit if necessary.
- Slowly inject refrigerant into the system and check suction and exhaust pressure.



## CAUTION

- **Connection must be renewed after injection is completed.**
  - **Never inject oxygen, acetylene or other flammable or poisonous gas to the refrigeration system at leakage detection and air tight test. Only pressurized nitrogen or refrigerant can be used.**
- 

## ■ Disassembling compressor

Follow the following procedures if compressor needs to be disassembled:

- 1) Cut off the power supply of unit.
- 2) Remove power source connection wire of compressor.
- 3) Remove suction and discharge pipes of compressor.
- 4) Remove fastening screw of compressor.
- 5) Move the compressor.

## ■ Auxiliary electric heater

When the ambient temperature is lower than 2℃, the heating efficiency decreases with the decline of the outdoor temperature. In order to make the air-cooled heat pump stably run in a relatively cold region and supplement some heat lost due to de-frosting. When the lowest ambient temperature in the user's region in winter is within 0℃~10℃, the user may consider to use auxiliary electric heater. Please refer to relevant professionals for the power of auxiliary electric heater.

In case of freezing at the water-side heat exchanger interval channel, severe damage may be caused, that is, heat exchange may be broken and appears leakage. This damage of frost crack is not within the warranty scope, so attention must be paid to antifreezing.

- ## RECORD TABLE OF TEST RUN AND MAINTENANCE

.42.

## RECORD TABLE OF TEST RUN AND MAINTENANCE


|  |                   |     |  |  |  |  |  |  |  |  |  |  |
|--|-------------------|-----|--|--|--|--|--|--|--|--|--|--|
| <b>Model:</b><br><b>Date:</b><br><b>Weather:</b><br><b>Operation time: Startup (                      )                      Shutdown (                      )</b> |                   |     |  |  |  |  |  |  |  |  |  |  |
| Outdoor<br>temperature   | Dry bulb          | ℃   |  |  |  |  |  |  |  |  |  |  |
|  | Wet bulb          | ℃   |  |  |  |  |  |  |  |  |  |  |
| Indoor temperature   |                   | ℃   |  |  |  |  |  |  |  |  |  |  |
| Compressor   | High pressure     | MPa |  |  |  |  |  |  |  |  |  |  |
|  | Low pressure      | MPa |  |  |  |  |  |  |  |  |  |  |
|  | Voltage           | V   |  |  |  |  |  |  |  |  |  |  |
|  | Current           | A   |  |  |  |  |  |  |  |  |  |  |
| Air temperature<br>of air-side heat<br>exchanger   | Inlet (Dry bulb)  | ℃   |  |  |  |  |  |  |  |  |  |  |
|  | Outlet (Dry bulb) | ℃   |  |  |  |  |  |  |  |  |  |  |
| Temperature of<br>chilled water or<br>hot water  | Inlet             | ℃   |  |  |  |  |  |  |  |  |  |  |
|  | Outlet            | ℃   |  |  |  |  |  |  |  |  |  |  |
| Current of cooling water pump or<br>hot water pump   |                   | A   |  |  |  |  |  |  |  |  |  |  |
| Notes :  |                   |     |  |  |  |  |  |  |  |  |  |  |

# TECHNICAL PARAMETERS

|                         |                                     |   |               |                |
|-------------------------|-------------------------------------|---|---------------|----------------|
| Cooling capacity        | kW                                  | 30  | 65            | 130            |
| Heating capacity        | kW                                  | 35  | 70            | 140            |
| Cooling consuming power | kW                                  | 11  | 22            | 44             |
| Cooling rated current   | A                                   | 19  | 38            | 78             |
| Heating consuming power | kW                                  | 10.5  | 21            | 42             |
| Heating rated current   | A                                   | 18  | 37            | 76             |
| Power supply            |                                     | 380-415V 3N~50Hz  |               |                |
| Operation control       |                                     | Control of wired controller, manual/auto startup, running state display, failure alert etc.                                   |               |                |
| Safety device           |                                     | High or low pressure switch, freeze-proof device, water flow protector, Over-current device, power phase sequence device etc. |               |                |
| Refrigerant             | Type                                | R410A   |               |                |
|                         | Charging Volume (kg)                | 6   | 6×2           | 6×4            |
| Water pipe system       | Water flux (m <sup>3</sup> /h)      | 5.16  | 11.18         | 22.36          |
|                         | Hydraulic resistance (kPa)          | 30  | 30            | 40             |
|                         | Water side heat exchanger           | Shell & tube type heat exchanger  |               |                |
|                         | Max. Pressure Mpa                   | 1.0   |               |                |
|                         | Inlet and outlet pipe dia.          | DN40  | DN100         | DN65           |
| Air side heat exchanger | Type                                | Fin coil model  |               |                |
|                         | Air flow volume (m <sup>3</sup> /h) | 12000   | 24000         | 48000          |
| Outline dimensions      | L mm                                | 1160  | 2000          | 2000           |
|                         | W mm                                | 900   | 900           | 1700           |
|                         | H mm                                | 2090  | 2090          | 2090           |
| Net weight              | kg                                  | 320   | 570           | 1100           |
| Operation weight        | kg                                  | 370   | 650           | 1200           |
| Packing dimension       | L×W×H (mm)                          | 1240×950×2250   | 2080×950×2250 | 2080×1740×2250 |

Attached Drawing


Electric wiring diagram of 30 kW unit (Applicable for LY516A Control panel)



Attached Drawing

Electric wiring diagram of 65kW unit (Applicable for LY516A Control panel)


Power supply: 380V 3N~ 50HZ






Attached Drawing

Electric wiring diagram of 130 kW unit (Applicable for LY516A Control panel)





**NOTE:**

1. The number of modules in each refrigerating system is not more than 16.
2. The specification of the signal line is the two-core RVV in 2x0.75mm<sup>2</sup>.

